

2024 AASHTO Bike Guide 5th Edition

REGIONAL SAFETY ADVISORY COMMITTEE
North Central Texas Council of Governments
Friday, January 24, 2025

Jeremy Chrzan, PE, PTOE
Multimodal Design Practice Lead

TOOLE
DESIGN

Guide for the Development of
BICYCLE FACILITIES
Fifth Edition

AASHTO American Association of State Highway and Transportation Officials 2024

1

1967 – 1972 Davis California

**3rd Street Bike Lane
(Rush Hour Parking Restricted)**

**BIKE LANE
(DAVIS TYPE A)**

**Sycamore Street
Barrier/Parking Protected Bike Lane**

**PROTECTED LANE
PHYSICAL SEPARATION
(DAVIS TYPE B)**

3

A Historical Perspective on the AASHTO Guide and the Impact of the Vehicular Cycling Movement

Bill Schultheiss, Rebecca Sanders, and Jennifer Toole

1972

2024

TOOLE
DESIGN

2

1974 AASHTO Bike Guide

GUIDE FOR
BICYCLE
ROUTES

Protected Bike Lanes & Intersections

Davis, California 1967

TOOLE
DESIGN

4

1974 AASHTO Bike Guide

Intersections and Crossings

Because the number and severity of conflicts between motorists, bicyclists, and pedestrians are greatest at intersections and crossings, utmost care must be taken in designing intersections which are to accommodate bicycle traffic. The safest and most effective way of eliminating conflicts where a bicycle route crosses another roadway is to provide a grade separation. This may be feasible in some cases, as discussed under grade separation structures. However, a grade separation usually cannot be provided because of lack of available space, especially where bicycle lanes or shared roadway exist at or near existing at-grade street intersections. Even where space is available, there seldom is warrant for the high cost of the structure. Therefore, a design which utilizes existing at-grade street intersections usually must be provided.

Whenever a bicycle lane is carried across an at-grade street intersection, some form of channelization with specific routings for bicycles should be provided to minimize the number of possible conflict points between bicycles, motor vehicles, and pedestrians within the intersection. Such channelization would not normally be necessary where shared roadways intersect a cross street, except where bicycle and motor vehicle traffic is heavy, motor vehicle speeds are in excess of 30 mph, or where there is a heavy percentage of motor vehicles making right turns out of the shared roadway.

Channelization usually consists of some form of striping or marking which clearly delineates the path which bicycles must take in crossing the intersection. In most cases the crossing should be achieved by a "right-of-way" approach from the pedestrian crosswalk. **Right-of-way** means the right to use the roadway in front of the cross street lane and **right-of-way** means the right to use the roadway in front of the cross street lane and **right-of-way** means the right to use the roadway in front of the cross street lane.

The undesirable effect of the conflict between right-turning motorists and straight-through bicyclists can be reduced to some extent by offsetting the bicycle crossing of the cross street away from the intersection.

Examples of channelization arrangements to accommodate bicyclists at intersections are illustrated in Figure 7. Figure 7(a) depicts a pair of bicycle lanes which are carried straight through the intersection with this arrangement, the bicycle route is a part of the street, directly aligned with the bicycle lane both upstream and downstream. The arrangement in Figure 7(b) likewise carries the bicycle lane through the intersection, but the bicycle route is offset from the

TOOLE DESIGN

5

1981 AASHTO Bike Guide

GUIDE FOR DEVELOPMENT OF NEW BICYCLE FACILITIES 1981

Published by American Association of State Highway and Transportation Officials, 444 North Capitol Street, N.W., Suite 225, Washington, D.C. 20001

TOOLE DESIGN

Protected Bike Lanes & Intersections

Davis, California 1967

7

1975 Effective Cycling

“Cyclists fare best when they act and are treated as drivers of vehicles”

John Forester

sixth edition **Effective Cycling**

TOOLE DESIGN

6

“Communities across the country are all different, but the AASHTO Bike Guide allows each of those communities to learn how to grow, maintain, and operate their bicycle infrastructure – allowing for more transportation options for those who cannot or choose not to drive”

AASHTO Executive Director Jim Tynon

TOOLE DESIGN

8

Who should the default design user be?



Experienced & Confident Bicyclist
AASHTO 1981 - 2012



Interested but Concerned Bicyclist
AASHTO 2024

9

AASHTO 2024 Chapter Outline

- | | |
|--|---|
| 1. Introduction | 10. Traffic Signals and Active Warning Devices |
| 2. Bicyclist Operation & Safety | 11. Bicycle Facility Design at Interchanges, Alternative Intersections, and Roundabouts |
| 3. Bicycle Planning | 14. Rural Area Bikeways and Roadways |
| 4. Guidance for Choosing a Bikeway Type | 14. Structures |
| 5. Elements of Design | 14. Wayfinding Systems for Bicyclists |
| 6. Design of Shared Use Paths | 15. Maintenance & Operations |
| 7. Design of Separated Bike Lanes and Side Paths | 16. Bicycle Parking, Bike Share Siting, and End of Trip Facilities |
| 8. Bicycle Boulevard Planning and Design | |
| 9. Design of Shared Lanes & Bicycle Lanes | |



11

2012 Guide compared to 2024 Guide

2012 Guide	2024 Guide	Notable Changes of 2024 compared to 2012
Chapter 1. Introduction	1. Introduction	REWRITE with new discussion of design range concept
Chapter 3. Bicycle Operation and Safety	2. Bicycle Operation & Safety	REWRITE of former Chapter 3
Chapter 2. Bicycle Planning	3. Bicycle Planning	REWRITE and NEW CONTENT added to former Chapter 2
	4. Facility Selection	NEW CHAPTER with a few items carried from Chapter 2
	5. Elements of Design	NEW CHAPTER with some content pulled from Chapters 4 and 5
Chapter 5. Design of Shared Use Paths	6. Shared Use Paths	REVISION of Chapter 5
	7. Separated Bike Lanes	NEW CHAPTER with new content
	8. Bicycle Boulevards	NEW CHAPTER with new content
Chapter 4. Design of On-Road Facilities	9. Bike Lanes & Shared Lanes	REVISION of Chapter 4
	10. Traffic Signals and Active Warning Devices	NEW CHAPTER with new content
	11. Roundabouts, Interchanges, and Alternative Intersections	NEW CHAPTER with new content
	12. Rural Area Bikeways	NEW CHAPTER with some content pulled from Chapter 4
	13. Structures	NEW CHAPTER with some content pulled from Chapter 5
	14. Wayfinding	NEW CHAPTER with some content pulled from Chapter 4
Chapter 7. Maintenance and Operations	15. Maintenance & Operations	REVISION of chapter 7
Chapter 6. Bicycle Parking Facilities	16. Parking, Bike Share, & End of Trip Facilities	REVISION of chapter 6




10


Chapter 1 – Introduction

- 1.1 Design Imperative for Bicycle Facilities
- 1.2 Purpose
- 1.3 Design Flexibility
- 1.4 Use of Values in the Guide
- 1.5 Scope
- 1.6 Relationship to other Design Guides and Manuals
- 1.7 Structure of this Guide
- 1.8 Definitions


12




13



15



14



16


Section 1.6 - Relationship to Other Manuals




FHWA Separated Bike Lane Planning and Design Guide
May 2015
TOOLE DESIGN



FHWA Achieving Multimodal Networks
August 2016



FHWA Accessible Shared Streets
September 2017



FHWA Measuring Multimodal Network Connectivity
February 2018

17

Experimental

AASHTO | GUIDE FOR THE DEVELOPMENT OF BICYCLE FACILITIES, 5TH EDITION

9.8. Advisory Bicycle Lanes (Experimental)

Advisory bicycle lanes are continuously-dotted bicycle lanes which permit motorists to temporarily enter the bicycle lane, allowing opposing motor vehicle traffic sufficient space to pass (see Figures 9-15 and 9-16). They are an experimental design treatment for streets with lower traffic speeds and volumes where it is not feasible to provide standard-width travel lanes and bicycle lanes. They are designed to improve bicyclist comfort while also providing a traffic calming benefit. This is the same procedure for motorists operating on yield streets where motorists must move to the right side of the road, into unoccupied parking spaces or driveways, to permit oncoming traffic to pass (see Section 8.4.1).



Figure 9-15: Example of an Advisory Bicycle Lane in Alexandria, VA

Where advisory bicycle lanes are installed, they should include bicycle lane signs (R3-17) and bicycle lane symbol pavement markings. The placement of the signs and bicycle lane symbols should follow guidance for bicycle lanes. Experimental approval from FHWA is required to use this traffic control treatment. See Section 1.6.1 for guidance on requests to experiment.

Advisory shoulders are a similar treatment used in locations where sidewalks are not provided. Bicycle symbols are omitted to allow pedestrians to share the shoulder space with bicyclists. Chapter 12 provides design guidance for advisory shoulders.

TOOLE DESIGN

19


1.6.1. Manual on Uniform Traffic Control Devices for Streets and Highways (MUTCD)

MUTCD defines design and application of traffic control devices (TCDs).

2024 Bike Guide conforms to 2023 MUTCD

Includes some TCDs that require experimental approval by FHWA (located at the end of their respective section)

AASHTO expands upon the application of TCDs



TOOLE DESIGN

18

Section 1.8 - Definitions

Bicyclist Design User Profile – A **generalized profile of different types of bicyclists based on their comfort when bicycling with motor vehicle traffic**, as well as their bicycling skills and experience. Profiles range from Highly Confident to Somewhat Confident to Interested but Concerned.

Bicycle Facilities – A **general term** denoting provisions to accommodate or encourage bicycling, including bikeways, bicycle boulevards, bicycle detection, in addition to parking and storage facilities.

Bikeway – Any road, path, or facility intended for bicycle travel which **designates separate space for bicyclists distinct from motor vehicle traffic or a bicycle boulevard designed for bicyclist travel priority**. A bikeway does not include shared lanes, sidewalks, signed routes, or shared lanes with shared lane markings.

TOOLE DESIGN

20

Chapter 2 - Bicycle Operation and Safety

- 2.1. Introduction
- 2.2 Safety of Bikeways and Shared Lanes
- 2.3. Bicyclist Design User Profiles
- 2.4. Bicyclist Safety and Performance Characteristics
- 2.5. Design Vehicle and Bicyclist Operating Criteria
- 2.6. Operating Principles for Bicyclists
- 2.7. Guiding Principles for Bicyclist Safety

21

2.2.1. Relationship between Perceived Comfort and Substantive Safety

Crashes and near-crash experiences influence perceived bicycling safety and comfort

(Lee et al., 2015; Sanders, 2015; Aldred & Crossweller, 2015)



TOOLE
DESIGN

23

2.2.1. Relationship between Perceived Comfort and Substantive Safety


Research has found a significant relationship between

- how safe and comfortable people feel bicycling,
- whether and how often they bicycle,
- preferences for facility types, and the provision of those facilities.

TOOLE
DESIGN

22

Comfort Increases with Separation



TOOLE
DESIGN

24

2.2.2. Safety in Numbers

Bicyclist risk does not increase proportionately to their increased volume, but actually **decreases as the number of bicyclists increases.**

Example
15th Street, NW
Washington DC

Shared Lane

2010: <100 cyclists /day




Separated Bike Lane

2017: 2,500 cyclists /day



TOOLE
DESIGN

2.3. Bicyclist Design User Profiles



TOOLE
DESIGN

Figure 2-2: Comfort Typology of Bicyclists (See Chapter 2 References: Dill and McNeill, 2016)

Foundational Change in Philosophy Underpinning the Guide

1980 – 2012 AASHTO Bike Guide Design User Profile = Confident Male Recreational Bicyclist



Wide Outside Lanes
Cycling Rates
1-2%

“Vehicular cycling...is faster and more enjoyable...the plain joy of cycling overrides the annoyance of even heavy traffic” - john forester

TOOLE
DESIGN

2.7. Guiding Principles for Bicyclist Safety




Figure 2-5: Typical Adult Bicyclist Operating Space

TOOLE
DESIGN

- Reduced injury risk compared to standard bike lanes and shared lanes (Lusk et al., 2013; Lusk et al., 2011; NYCDOT, 2014; Winters et al., 2013)
- SBL preferred over striped or shared lanes by both cyclists and motorists (Monsere et al., 2014; Monsere et al., 2012; Sanders, 2014)
- One-way generally safer than two-way (Schepers et al., 2011; Thomas & DeRobertis, 2013)
- Two-way SBLs on one-way roads, preferable on right side (Schepers et al., 2011; Zangenehpour et al., 2015)

Chapter 3: Bicycle Planning

- 3.1 Introduction
- 3.2 Bicycle Planning Principles
- 3.3 Primary Considerations for Bicycle Planning
- 3.4 Planning For Desired Outcomes
- 3.5 Deciding Where Improvements Are Needed
- 3.6 Integrating Bicycle Facilities with Transit (First- and Last-Mile Connections)
- 3.7 Bike Parking and End of Trip Support
- 3.8 Types of Transportation Planning Processes
- 3.9 Technical Analysis Tools That Support Bicycle Planning
- 3.10 Public Input

29

3.9.2. Quality of Service and Bicycle Level of Service Tools

3.9.2.2 Level of Traffic Stress

objective and quantitative method of classifying road segments and bikeway networks based on how comfortable bicyclists



Figure 3-3. Example of Bicycle Master Plan Recommendations Map¹⁰


Table 3-4. Levels of Traffic Stress¹⁰

Levels of Traffic Stress (LTS)	
LTS 1	Presenting little traffic stress and demanding little attention from cyclists, and attractive enough for a relaxing bike ride. Suitable for almost all cyclists, including children trained to safely cross intersections. On links, cyclists are either physically separated from traffic, or are in an exclusive bikeway next to a slow traffic stream with no more than one lane per direction, or are on a shared road where they interact with only occasional motor vehicles (as opposed to a stream of traffic) with a low speed differential. Where cyclists ride alongside a parking lane, they have ample operating space outside the zone into which car doors are opened. Intersections are easy to approach and cross.
LTS 2	Presenting little traffic stress, and therefore suitable to most adult cyclists but demanding more attention than might be expected from children. On links, cyclists are either physically separated from traffic, or are in an exclusive bicycling zone next to a well-coordinated traffic stream with adequate clearance from a parking lane, or are on a shared road where they interact with only occasional motor vehicles (as opposed to a stream of traffic) with a low speed differential. Where a bike lane lies between a through lane and a right-turn lane, it is configured to give cyclists unambiguous priority where motor vehicles cross the bike lane and to keep speeds in the right-turn lane comparable to bicycling speeds. Crossings are not difficult for most adults.
LTS 3	More traffic stress than LTS 2, yet markedly less than the stress of integrating with multilane traffic, and therefore welcome to many people currently riding bikes in American cities. Offering cyclists either an exclusive bikeway next to moderate-speed traffic or shared lanes on streets that are not multilane and have moderately low speed. Crossing may be longer or across higher-speed roads than allowed by LTS 2, but still considered acceptably safe to most adult bicyclists.
LTS 4	A level of stress beyond LTS 3. Bicyclist mix with motor vehicle traffic. Generally uncomfortable for most adults.

31

Bicycle Planning Principles

- 3.2.1. **Safety** – reduce frequency and severity of crashes by separating bicyclists from higher speed and volumes of motorists
- 3.2.2. **Comfort** – do not deter use due to safety concerns
- 3.2.3. **Connectivity** – direct, complete and continuous
- 3.2.4. **Legibility** – easy to recognize and intuitive to use



Improved Bicycle Connectivity within poorly connected road network
Improved Bicycle Connectivity within well connected road network
Figure 3-1: Examples of Contrasting Connectivity

TOOLE DESIGN

30

Chapter 4 - Guidance for Choosing a Bikeway Type

- 4.1 Introduction
- 4.2 Project Performance Goals and Objectives
- 4.3 Selecting the Preferred Bikeway Type
- 4.4 Strategies to Achieve the Preferred (or Next Best) Design
- 4.5 Evaluating Design Alternatives and Trade-offs to Select a Bikeway


32

Section 4.3.1 – Streets in Urban, Suburban and Rural Town Contexts

Identifies the **preferred** bikeway type assuming:

Design User = Interested but Concerned bicyclist

Analysis = Level of Traffic Stress



4.4.2. Example Strategies for Constrained Rights-of-Way

- 4.4.2.1 Traffic Analysis Approach
- 4.4.2.2 Narrowing Travel Lanes
- 4.4.2.3 Removing Travel Lanes
- 4.4.2.4 Reorganizing Street Space
- 4.4.2.5 Making Changes to On-Street Parking
- 4.4.2.6 Reducing Bikeway Widths
- 4.4.2.7 Reducing Motor Vehicle Traffic Volumes and Speeds

4.5.2. Example of Trade-off Considerations Between Common Bikeway Types




Figure 4-3. Common Bikeway Options within a 48-ft Cross Section




Section 4.3.2 – Rural Roadways

Identifies the **preferred** shoulder width assuming:

Design User = Confident bicyclist

Analysis = Bicycle LOS

Figure 4-2: Preferred Paved Shoulder Widths for Rural Roadways to Accommodate Highly Confident or Somewhat Confident Bicyclists




4.5.3. Selecting the Next Best Facility When the Preferred Bikeway Is Not Feasible

Alternative Route

If no other design improvements are feasible, it is necessary to consider alternative parallel routes.

Research indicates that for an alternative low-stress route to be viable, **the increase in trip length should be less than 30 percent.**

Broach, J., Dill, J., and J. Glebe. Where Do Cyclists Ride? A Route Choice Model Developed with Revealed Preference GPS Data



Chapter 5 – Elements of Design

- 5.1 Introduction
- 5.2 Design User
- 5.3 Design Speed
- 5.4 Understanding Assignment of Right of Way
- 5.5 Sight Distance
- 5.6 Surface and Geometric Design Elements
- 5.7 Characteristics of Intersections
- 5.8 Intersection Design Objectives
- 5.9 Evaluating Bicycle and Pedestrian Roadway Crossings
- 5.10 Geometric Design Treatments to Improve Intersection Safety
- 5.11 Warning and Regulatory Traffic Control Devices
- 5.12 Pavement Markings
- 5.13 Bicycle Travel Near Rail Lines
- 5.14 Other Design Features

37

5.5.2. Stopping Sight Distance

Tables provided for:

- Unexpected Conflict, 2.5 second PRT
- Expected Conflict, 1.5 second PRT

Table 5-2: Minimum Bicyclist Stopping Sight Distance vs. Grades for Various Design Speeds—2.5-Second Reaction Time

Stopping Sight Distance (ft) Based on Speed and Grade for a 2.5-Second Perception-Reaction Time											
Speed (mph)	Grade (Positive indicates ascending)										
	-10%	-8%	-6%	-4%	-2%	0	2%	4%	6%	8%	10%
10				65	61	58	55	53	52	51	50
11				74	69	66	63	61	59	57	56
12				84	78	74	71	68	66	64	62
15			130	118	109	102	97	93	89	86	84
18	246	201	174	156	143	134	126	120	115	111	108
20	296	240	207	185	169	157	148	140	134	129	
25	440	353	300	266	241	222	208	196	187		
30	611	486	411	361	325	298	277	260			

Note: Calculations are assumed under wet conditions.

Table 5-3: Minimum Bicyclist Stopping Sight Distance vs. Grades for Various Design Speeds—1.5-Second Reaction Time

Stopping Sight Distance (ft) Based on Speed and Grade for a 1.5-Second Perception-Reaction Time											
Speed (mph)	Grade (Positive indicates ascending)										
	-10%	-8%	-6%	-4%	-2%	0	2%	4%	6%	8%	10%
10%				50	46	43	41	39	37	36	35
11				58	53	49	47	44	43	41	40
12				66	61	56	53	50	48	46	45
15			108	96	90	87	80	75	71	67	64
18	220	175	148	130	117	107	100	94	89	85	81
20	267	211	178	155	139	128	118	111	105	100	
25	403	316	264	229	204	185	171	159	150		
30	567	442	367	317	281	254	233	216			

Note: Calculations are assumed under wet conditions.




39

Section 5.4 – Understanding Assignment of Right of Way

All street users need opportunity for Mutual Identification because:

- Motorists & bicyclists must yield to pedestrians in crosswalks
- Pedestrians cannot suddenly leave the curb if vehicles too close to stop
- Motorists must exercise due care to avoid colliding with bicyclists/peds

The approach to a conflict point is composed of three zones.



38

5.5.4.1 Sight Distance and Approach Clear Space for Bikeways at Roadway Intersections

- **Turning Motorist Yields to (or Stops for) Through Bicyclists:**
When a through moving bicyclist that arrives or will arrive at the crossing prior to a turning motorist, the motorist must stop or yield.
- **Through Bicyclist Yields to (or Stops for) Turning Motorist:**
When a turning motorist arrives or will arrive at the crossing prior to a through moving bicyclist, the bicyclist must stop or yield.
- **User with Right-of-Way Yields to (or Stops for) Another User:** Sometimes the user with the right-of-way will instead yield the right-of-way.
- **APPROACH CLEAR SPACE ALLOWS THIS TO FUNCTION!**



40


5.5.4.1.1 Case S – Right-Turning Motorist Across Separated Bike Lane or Side Path

Table 5-4: Recommended Intersection Approach Clear Space by Vehicular Turning Design Speed

Effective Vehicle Turning Radius	Vehicular Turning Speed	Recommended Approach Clear Space
<18 ft	<10 mph*	20 ft
18 ft	10 mph	40 ft
25 ft	15 mph	50 ft
30 ft	20 mph	60 ft
>30 ft	25 mph	70 ft

* Most low-volume driveways and alleys


Legend
 line of sight



TOOLE
DESIGN

41

7.9.5 Case U1 – Multistep Variant



Chapter 7 sight distance


- Driver looks for pedestrians, then moves forward
- Driver looks for bicyclists, then moves forward
- Driver looks for other motorists, then proceeds

Legend
 Case U1 sight triangles
 AASHTO Green Book Case B sight triangles

TOOLE
DESIGN

43

5.5.4.1.3 Case U1 – Through Motorist Crossing of a Separated Bike Lane or Shared Use Path



at a minimum the provision of stopping sight distance for bicyclists (Section 5.5.2) should be provided to allow a bicyclist to slow or stop if a vehicle encroaches into the separated bike lane or side path

Legend
 Case U1 sight triangles

Figure 5-3: Intersection Sight Distance: Case U1

TOOLE
DESIGN

42

5.5.4.1.3.3 U3 – Mid-Block Shared Use Path Crossing of an Uncontrolled Roadway




Figure 5-5: Sight Triangle for Uncontrolled Mid-Block Path Crossing of an Uncontrolled Roadway: Case U3

Table 5-8: Length of Path and Roadway Sight Triangle for Uncontrolled Crossings: Case U3

Bike Speed (mph)	Roadway Speed (mph)							
	15	20	25	30	35	40	45	50
10	99	58	125	160	190	224	255	281
11	97	56	123	157	187	220	250	276
12	96	54	121	155	185	218	248	274
15	105	70	140	174	209	244	279	305
18	112	87	158	197	235	272	309	336
20	118	105	174	217	258	297	335	362
25	133	145	197	247	298	349	399	449
30	149	169	225	285	346	407	467	527

a = sight distance (ft) along roadway
 b = sight distance (ft) along path
 Assumptions: Bicycle reaction time = 1.5 seconds
 Width of path = 10 to 11 ft
 Width of road lane = 11 ft to 12 ft
 Length of bicycle = 6 ft
 Length of motor vehicle = 18 ft
 Grade = -2 percent to +2 percent

TOOLE
DESIGN

44

5.5.4.3 Sight Distance at Horizontal Curves

Figure 5-10: Diagram illustrating Components for Determining Horizontal Sightline Offset

TOOLE DESIGN

R (ft)	S = Stopping Sight Distance (ft)													
	40	60	80	100	120	140	160	180	200	220	240	260	280	300
25	7.6	15.9												
50	3.8	8.7	16.2	23.9	31.9	41.5								
75	2.7	5.9	10.4	16.1	22.9	30.4	39.4	47.6	57.4	67.2				
100	4.5	7.8	12.2	17.0	22.0	28.0	35.0	44.0	53.0	63.0	72.0	82.0	92.0	102.0
125	3.6	6.3	9.9	14.1	18.1	24.7	31.6	37.9	45.4	53.3	61.7	70.4	79.3	88.3
150	3.0	5.3	8.3	11.6	15.0	20.0	26.2	32.1	38.9	45.5	52.9	60.7	68.9	77.5
175	2.6	4.6	7.4	10.2	13.6	18.0	23.6	27.6	33.5	39.8	46.1	53.1	60.5	68.5
200	4.8	8.2	12.8	17.1	21.8	28.5	35.5	44.0	54.0	64.0	74.0	84.0	94.0	104.0
225	3.5	5.5	8.9	12.8	16.1	21.0	26.4	31.9	38.3	45.2	52.4	60.2	68.2	76.5
250	3.0	5.0	8.2	11.7	15.2	20.0	25.6	31.2	37.6	44.5	51.9	59.7	67.7	76.0
275	2.6	4.5	7.5	10.8	14.4	18.8	24.1	27.5	33.5	40.2	47.4	55.0	62.8	71.0
300	2.7	4.2	7.0	10.0	13.4	18.0	23.7	27.2	33.2	40.0	47.2	54.8	62.5	70.5
325	3.4	5.1	7.9	11.1	14.5	19.2	24.8	29.4	35.4	42.0	49.2	56.8	64.5	72.5
350	3.1	4.8	7.6	10.7	14.1	18.8	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
375	2.8	4.6	7.4	10.6	14.0	18.7	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
400	2.5	4.4	7.2	10.4	13.8	18.5	24.0	28.6	34.6	41.2	48.4	56.0	63.7	71.7
425	3.3	4.9	7.7	10.9	14.3	19.0	24.6	29.2	35.2	41.8	48.9	56.5	64.2	72.2
450	2.9	4.7	7.5	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
475	3.1	4.8	7.6	10.9	14.3	19.0	24.5	29.1	35.1	41.7	48.9	56.5	64.2	72.2
500	2.7	4.6	7.4	10.7	14.1	18.8	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
525	3.2	4.8	7.6	10.9	14.3	19.0	24.5	29.1	35.1	41.7	48.9	56.5	64.2	72.2
550	2.8	4.5	7.3	10.6	14.0	18.7	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
575	3.0	4.7	7.5	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
600	2.7	4.4	7.2	10.5	13.9	18.6	24.0	28.6	34.6	41.2	48.4	56.0	63.7	71.7
625	3.3	4.9	7.7	10.9	14.3	19.0	24.5	29.1	35.1	41.7	48.9	56.5	64.2	72.2
650	2.9	4.6	7.4	10.7	14.1	18.8	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
675	3.1	4.7	7.5	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
700	2.8	4.5	7.3	10.6	14.0	18.7	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
725	3.0	4.6	7.4	10.7	14.1	18.8	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
750	2.7	4.4	7.2	10.5	13.9	18.6	24.0	28.6	34.6	41.2	48.4	56.0	63.7	71.7
775	3.2	4.8	7.6	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
800	2.9	4.6	7.4	10.7	14.1	18.8	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
825	3.1	4.7	7.5	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
850	2.8	4.5	7.3	10.6	14.0	18.7	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
875	3.0	4.6	7.4	10.7	14.1	18.8	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
900	2.7	4.4	7.2	10.5	13.9	18.6	24.0	28.6	34.6	41.2	48.4	56.0	63.7	71.7
925	3.2	4.8	7.6	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
950	2.9	4.6	7.4	10.7	14.1	18.8	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9
975	3.1	4.7	7.5	10.8	14.2	18.9	24.4	29.0	35.0	41.6	48.8	56.4	64.1	72.1
1000	2.8	4.5	7.3	10.6	14.0	18.7	24.2	28.8	34.8	41.4	48.6	56.2	63.9	71.9

Table 5-12: Horizontal Sightline Offset for Horizontal Curves Equation

$$HSO = R \left[1 - \frac{S^2}{2R^2} \right]$$

where:
 S = stopping sight distance (ft)
 R = radius of curvature of lane (ft)
 HSO = horizontal sightline offset, distance from centerline of lane to obstruction (ft)

Note: High R values are truncated in original image.

45

5.9.2. Evaluations of Uncontrolled Roadway Approaches to Bicycle Crossings

5.9.2.1 Factors That Impact Motorist Yielding Rates

5.9.2.2.1 Recommended Crossing Opportunities

Table 5-14: Recommended Minimum Range of Hourly Crossing Opportunities

Major Street Crossings (opportunities per hour)
Recommended: ≥ 120
Practical Minimum: 60 to < 120

Figure 5-14: Motorist Yielding at Uncontrolled Crossings Based on Roadway Characteristics

TOOLE DESIGN

47

5.8. Intersection Design Objectives

- 5.8.1. Minimize Exposure to Conflicts
- 5.8.2. Reduce Speeds at Conflict Points
- 5.8.3. Communicate Right-of-Way Priority
- 5.8.4. Providing Adequate Sight Distance
- 5.8.5. Transitions to Other Facilities
- 5.8.6. Accommodating Persons with Disabilities

Figure 5-13: Comparison of Bicyclist Exposure to Motor Vehicles at Intersections

TOOLE DESIGN

46

5.9.2.3 Apply Countermeasures to Improve Yielding

Table 5-15: Uncontrolled Crossing Evaluation

Tier 1: Signing & Markings

Tier 2: RRFB & Geometric Improvements

Tier 3: PHB, Signal, or Grade Separation

Roadway Type	Vehicle ADT < 9,000		Vehicle ADT 9,000 - 12,000		Vehicle ADT 12,000 - 15,000		Vehicle ADT > 15,000					
	S30	S5	40²	S30	S5	40²	S30	S5	40²			
2 Lanes^A	1	1	2	1	1	2	1	1	2	3		
3 Lanes with Raised Median^B	1	1	2	1	1	2	1	2	3	2	3	
3 Lanes without Raised Median^C	1	1	2	1	2	2	2	3	3	2	3	3
4 Lanes with Raised Median^D	1	1	2	1	2	2	2	3	3	3	3	3
4+ Lanes without Raised Median	1	2	3	2	2	2	2	3	3	3	3	3

Footnotes:
 ^A Where the speed limit exceeds 40 mph, Tier 3 should be considered.
 ^B 1 lane in each direction.
 ^C Raised medians must be at least 6 ft wide to serve pedestrians. See Figure 2-4 for different bicycle lengths to serve bicyclists.
 ^D Where median width is less than those values, review category of 4+ lanes without raised median.
 ^E 2 lanes in each direction.

TOOLE DESIGN

48

Section 5.10 – Geometric Design Treatments to Improve Intersection Safety

- 5.10.1 Medians and Pedestrian Refuge Islands; Hardened Centerlines
- 5.10.2 Curb Extensions
- 5.10.3 Curb Radius
- 5.10.4 Mountable Truck Aprons**
- 5.10.5 Raised Crossings
- 5.10.6 Multiple Threat Crossing Treatments
- 5.10.7 Bike Ramps
- 5.10.8 Directional Indicators




Figure 5-18: Mountable Truck Apron



49

Section 5.10 – Geometric Design Treatments to Improve Intersection Safety

- 5.10.1 Medians and Pedestrian Refuge Islands; Hardened Centerlines
- 5.10.2 Curb Extensions
- 5.10.3 Curb Radius
- 5.10.4 Mountable Truck Aprons
- 5.10.5 Raised Crossings**
- 5.10.6 Multiple Threat Crossing Treatments
- 5.10.7 Bike Ramps
- 5.10.8 Directional Indicators




Figure 5-20: Raised Side Street Crossing



51


Curb Radius Decisions vs Design Vehicle



50

Section 5.10 – Geometric Design Treatments to Improve Intersection Safety

- 5.10.1 Medians and Pedestrian Refuge Islands; Hardened Centerlines
- 5.10.2 Curb Extensions
- 5.10.3 Curb Radius
- 5.10.4 Mountable Truck Aprons
- 5.10.5 Raised Crossings
- 5.10.6 Multiple Threat Crossing Treatments
- 5.10.7 Bike Ramps**
- 5.10.8 Directional Indicators



52

Chapter 6 SUP Width (Two-way)

6.4.3. Recommended Shared Use Path Widths

Table 6-3: Recommended Shared Use Path Widths* to Achieve SUP LOS 'C'

Shared Use Path Operating Widths and Operational Lanes*					
SUPLOS "C" Peak Hour Volumes	Recommended Operational Lanes	Practical Minimum	Recommended Lower Limit	Recommended Upper Limit	Practical Maximum
150 to 300	2	8 ft	10 ft	12 ft	13 ft
300 to 500	3	11 ft	12 ft	15 ft	16 ft
500 to >600	4	15 ft	16 ft	20 ft	None

*Typical Mode Split is 55% adult bicyclists, 20% pedestrians, 10% runners, 10% in-line skaters, and 5% child bicyclists

11' wide provides three (3) operational lanes



6.4.4. Separation of Pedestrians and Bicyclists

6.4.4.1 Land Use Considerations Where Separation is Desirable

6.4.4.2 Volume Thresholds Where Separation is Desirable

Should be considered when:

- Level of Service is projected to be at or below level "C."
- Pedestrians can reasonably be anticipated to be 30% or more of the volume

6.4.4.3 Separation Strategies

6.4.4.4 Accessibility Considerations



Figure 6-2: Burke-Gilman Shared Use Path (2008) and Separated Paths (2021), Seattle, WA




Figure 6-4: Options for Separating Bicycles and Other Wheeled Users from Pedestrians



6.4.2. Shared Use Path Level of Service

Table 6-1: Shared Use Path Operating Conditions Based on Level of Service Criteria

Shared Use Path Level of Service (SUPLOS) and Operating Conditions	
SUPLOS	Peak Operating Conditions
A. Excellent	A significant ability to absorb more users across all modes is available.
B. Good	A moderate ability to absorb more users across all modes is available.
C. Fair	Path is close to functional capacity with minimal ability to absorb more users.
D. Poor	Path is at its functional capacity. Additional users will create operational and safety problems.
E. Very Poor	Path operating beyond its functional capacity resulting in conflicts and people avoiding the path.
F. Failing	Path operating beyond functional capacity resulting in significant conflicts and people avoiding the path.

Table 6-2: Shared Use Path Level of Service Look-Up Table, Typical Mode Split

Shared Use Path Peak Hour Volume	Shared Use Path Width (ft)										
	8	10	11	12	14	15	16	18	20	≥ 25	
50	B	B	B	B	B	A	A	A	A	A	
100	D	C	B	B	B	A	A	A	A	A	
150	D	C	B	B	B	A	B	A	A	A	
200	D	D	C	B	B	A	B	A	A	A	
300	E	D	C	C	C	B	B	B	B	A	
400	F	E	D	D	C	C	B	B	B	A	
500	F	F	D	D	C	C	C	C	A	A	
600	F	F	E	E	D	D	C	C	A	A	
800	F	F	F	F	F	E	E	E	A	A	
1,000	F	F	F	F	F	F	F	F	F	A	
≥ 1,200	F	F	F	F	F	F	F	F	F	A	

- *Assumptions:
- Mode split is 55 percent adult bicyclists, 20 percent pedestrians, 10 percent runners, 10 percent in-line skaters, and 5 percent child bicyclists.
 - An equal number of trail users travel in each direction (the model uses a 50 percent-50 percent directional split).
 - Trial volume represents the actual number of users counted in the field (the model adjusts this volume based on a peak hour factor of 0.85).
 - Trial has a centerline.



6.6. General Design Considerations

6.6.1. Shy Distance, Clearances, and Shoulders




Figure 6-5: Shoulders and Shy Distance on Shared Use Path



6.6.3. Horizontal Alignment

Table 6-5: Minimum Radii for Horizontal Curves at 20-Degree Lean Angles

Design Speed (mph)	Minimum Radii (ft) for Horizontal Curves at 20-Degree Lean Angles
8	12
10	18
12	27
14	36
16	47
18	60
20	74
25	115
30	166

6.6.4. Vertical Alignment


Table 6-7: Length of Crest Vertical Curve to Provide Sight Distance Equations

Length of Crest Vertical Curve to Provide Sight Distance Equations	
when $S > L$:	$L = \frac{2.15 A S^2}{V^2}$
when $S < L$:	$L = \frac{A S^2}{100(2S - A)^2}$
where:	
L	= minimum length of vertical curve (ft)
A	= algebraic grade difference (percent)
S	= stopping sight distance for flat grade (ft)
A_1	= eye height (3.5 ft for a typical unobstructed bicyclist)
A_2	= object height (0 ft)

*See Tables 5.1 and 5.3



6.7. Shared Use Path Intersections and Transitions



TOOLE DESIGN

61

7.2. General Design Considerations

- The cross section of a separated bike lane comprises three distinct zones (see Figure 7-1):
- 1 Bike lane**—The bike lane is the space in which the bicyclist operates. It is located between the street buffer and the sidewalk buffer.
 - 2 Street buffer**—The street buffer separates the bike lane or side path from motor vehicle traffic.
 - 3 Sidewalk buffer**—The sidewalk buffer separates the bike lane from the sidewalk.




Figure 7-1: Separated Bike Lane Zones

TOOLE DESIGN

63

Chapter 7 – Separated Bike Lanes and Side Paths

- 7.1 Introduction
- 7.2 General Design Considerations
- 7.3 Bike Lane Zone
- 7.4 Street Buffer Zone
- 7.5 Sidewalk Buffer Zone
- 7.6 Consideration for Zone Widths in Constrained Locations
- 7.7 Utility Considerations
- 7.8 Landscaping Considerations
- 7.9 Separated Bikeway and Side Path Intersection Design
- 7.10 Transitions Between Facilities
- 7.11 Raised Bike Lanes

62

7.2.2.3 Intermediate-Level Separated Bike Lanes

curb reveal of 2-3 in. below sidewalk elevation is recommended to"

- provide vertical separation to the adjacent sidewalk, and
- provide a detectable edge for pedestrians with vision disabilities




Figure 7-3: Curb Types for Separated Bike Lanes




Figure 7-4: Intermediate-Level Separated Bike Lane

TOOLE DESIGN

64

Section 7.3.4 – SBL Width (One-way)

Table 7-3: One-Way Separated Bike Lane Widths Based on Existing or Anticipated Volumes

Peak Hour Directional Bicyclist Volume	One-Way Separated Bike Lane Width (ft) Recommended Values		
	Between Vertical Curbs without Gutter	Adjacent to One Vertical Curb	Between Stopped Curb, at Sidewalk Level, or Adjacent to Curb with Gutter
<150	6.5–8.5	6–8	5.5–7.5
150–750	8.5–10	8–9.5	7.5–9
>750	≥10	≥9.5	≥9
Practical Minimum*	4.5	4	4

*Peak Hour Directional Bicyclist Volume not applicable






Figure 7-7: Separated Bike Lane Width

7.9. Separated Bike Lane and Side Path Intersection Design

- 7.9.1. Minimizing Exposure to Conflicts
- 7.9.2. Reducing Speeds at Conflict Points
- 7.9.3. Transitions between Elevations
- 7.9.4. Right-of-Way Priority
- 7.9.5. Sight Distance
- 7.9.6. Restricting Motor Vehicles





Figure 7-10: Protected Intersection Design for Separated Bike Lanes and Side Paths



7.7.1. Drainage and Stormwater Management




Figure 7-11: Examples of Separated Bike Lane Drainage Options




Figure 7-10: Green Stormwater Infrastructure in an Urban Street Context

7.9.7.1 Corner Island

Benefits:

- forward bicycle queuing area
- space for turning vehicles to wait
- reduces crossing distances
- reduces motorist turning speeds
- can reduce bicyclist speeds by adding deflection to the bike lane or side path



Figure 7-15: Corner Island with Flexible Delineator Posts (Source: Carl Sundstrom, PE, Office of Bicycle and Pedestrian Programs, New York City Department of Transportation)




Figure 7-16: Bend-Out Example




Figure 7-17: Side Path Curb Ramps at Constrained Intersection



7.9.9. Intersection Design with Mixing Zones

Reduce speeds of motor vehicles entering the merge point to 20 mph or less:

- Minimize the length of the merge area
- Locate the merge point as close as practical to the intersection.
- Minimize the length of the storage portion of the turn lane.
- Provide a buffer and physical separation (e.g., flexible delineator posts) from the adjacent through lane after the merge area, if feasible.
- Highlight the conflict area with a green-colored pavement and dotted bike lane markings (see Figure 7-20), as necessary, or shared lane markings (see Figure 7-21).
- Raise the elevation of the turn lane at the start of the mixing zone.




Figure 7-20: Angled Crossing Mixing Zone with Bike Lane
Figure 7-21: Angled Crossing Mixing Zone with Shared Lane



7.9.14. Transit Stops







Figure 7-24: Example Configuration: Floating Transit Stop (Mid-Block)



ALTERNATIVE 1



ALTERNATIVE 2




ALTERNATIVE 3

Note: Directional indicators are an emerging treatment. See Sections 5.10.3 for recommendations for implementation.

Figure 7-31: Example Configurations: Floating Transit Stop (Near-Side)



7.9.12.1 Accessible Motor Vehicle Parking



Accessible On-Street Motor Vehicle Parking at Intersections



7.10. Transitions between Facilities

In general, it is preferable for a transition from a separated bike lane to a standard bicycle lane or shared lane to occur on the far side of the intersection.




Figure 7-32: Transition to Shared Lane




Figure 7-35: Transition from One-Way to Two-Way Separated Bike Lanes at Protected Intersection



7.11. Raised Bike Lanes

Table 7-5: Raised Bike Lane Widths

Raised Bike Lane Widths				
Bike Lane Context	Practical Minimum (ft)	Recommended Lower Limit (ft)	Recommended Upper Limit (ft)	Practical Maximum (ft)
Intermediate level or sidewalk level raised bike lane	5	6.5	8	10

*Raised bike lane widths are exclusive of the gutter unless the gutter is integrated into the full widths of the bike lane.
 **Separated bike lane with a street buffer may be preferable to a curb-attached, wide raised bike lane.




Figure 7-10: Raised Bike Lane Transitions at Intersections




Figure 7-20: Intermediate-Level and Sidewalk-Level Raised Bike Lanes



Section 8.2 – Bicycle Boulevard Principles

Bicycle Boulevards are not just signed bike routes.

Principles that set them apart from local streets include:

- 8.2.1. Manage motorized through traffic volumes and speeds
- 8.2.2. Prioritize right-of-way at local street crossings
- 8.2.3. Provide safe and convenient crossings at major streets

Minimize Motorized Through Traffic Volumes and Speed Differential			
	Hourly Traffic Volume	Daily Traffic Volume	Speed
Preferred	50 vehicles/hr	1,000 ADT	15 mph
Acceptable	75 vehicles/hr	2,000 ADT	20 mph
Maximum	100 vehicles/hr	3,000 ADT	25 mph

Major Street Crossings (opportunities per hour)	
Preferred	120
Minimum	60



Chapter 8 – Bicycle Boulevard Planning and Design

- 8.1 Introduction
- 8.2 Bicycle Boulevard Principles
- 8.3 Bicycle Boulevard Minimum Design Elements
- 8.4 Traffic Calming Strategies (Speed Management)
- 8.5 Traffic Diversion Strategies (Volume Management)
- 8.6 Traffic Control for Minor Street Crossings
- 8.7 Traffic Control for Major Street Crossings

8.4. Traffic Calming Strategies (speed management)



Figure 8-5: Example of a Chicane Treatment on a Two-Way Street Created by a Median and Curb Extensions



Figure 8-6: Example of a Chicane Treatment Created by Alternating Parking from One Side of the Street to the Other



8.5. Traffic Calming Strategies (volume management)




Figure 8-10: Example of a Median Used to Create a Diagonal Barrier at Intersection of Two Local Streets.



Figure 8-11: Example of a Median Used to Divert Traffic at a Major Street Crossing

TOOLE
DESIGN

Chapter 9 – Shared Lanes and Bicycle Lanes

- 9.1 Introduction
- 9.2 Design User Profile Considerations
- 9.3 Shared Lanes and Shared Roadways
- 9.4 Bicycle Lane Considerations
- 9.5 Buffered Bicycle Lanes
- 9.6 Bicycle Lane Considerations Adjacent To Parking and Loading
- 9.7 Bicycle Lane Considerations at Bus Stops
- 9.8 Advisory Bicycle Lanes (Experimental)
- 9.9 Bicycle Lanes on One-Way Streets
- 9.10 Bicycle Lanes on One Side of Two-Way Streets
- 9.11 Counterflow Bicycle Lanes
- 9.12 Bicycle Lanes at Intersections, Driveways, and Alleys

8.7. Traffic Controls for Major Street Crossings




Figure 8-15: Example of Connecting Offset Bicycle Boulevard Segments Using a Two-Way Separated Bike Lane



Figure 8-16: Example of Connecting Offset Bicycle Boulevard Segments Using a Blue Lane and Two-Stage Bicycle Turn Boxes

TOOLE
DESIGN

9.3.2. Limited Effectiveness of Wide Outside Lanes

Figure 9-1: Shared Lane Conditions (Rural Context, Suburban Context, Urban Context)




Rural Roadway



Suburban Arterial

Figure 9-2: Shared Lane Marking Lateral Placement in Travel Lanes - 14 Feet Without Parking



TOOLE
DESIGN

9.4.1. Bicycle Lane Widths

Table 9-1 One-Way Standard Bicycle Lane Widths

Bike Lane Context	Practical Minimum (ft)	Recommended Lower Limit (ft)	Recommended Upper Limit (ft)	Practical Maximum (ft)
Adjacent to edge of Pavement	4'	5'	7'	8'
Adjacent to curb (exclusive of gutter)	5'	6'	7'	8'
Between through lanes and turn lanes	5'	6'	7'	8'
Between buffers	4'	5'	7'	8'
Adjacent to parking	5'	6'	7'	8'
To allow occasional passing or side-by-side bicycling*	6.5'	8'	10'	11'

Notes
 *Shoulders should be provided in lieu of narrow bicycle lanes to avoid confusion below the practical minimum width.
 *Buffers are desirable where bicycle lanes are located between through lanes and turn lanes, especially as motorist speeds exceed 30 mph.
 *Buffered bike lanes or separated bike lanes should be considered in lieu of side-by-side bicycle lanes to avoid confusion with a parking or travel lane.
 *A minimum of 6.5 ft is necessary for occasional passing and 8 ft or more for comfortable side-by-side bicycling.



9.5. Buffered Bicycle Lanes




Figure 9-9. Buffer Design Options

9.8. Advisory Bicycle Lanes (Experimental)

Advisory bicycle lanes are continuously-dotted bicycle lanes which permit motorists to temporarily enter the bicycle lane, allowing opposing motor vehicle traffic sufficient space to pass (see Figures 9-15 and 9-16). They are an experimental design treatment for streets with lower traffic speeds and volumes where it is not feasible to provide standard-width travel lanes and bicycle lanes. They are designed to improve bicyclist comfort while also providing a traffic calming benefit. This is the same procedure for motorists operating on yield streets where motorists must move to the right side of the road, into unoccupied parking spaces or driveways, to permit oncoming traffic to pass (see Section 8.4.1).



Figure 9-15: Example of an Advisory Bicycle Lane in Alexandria, VA

Groundbreaking to include experimental treatments to guide practitioners on emerging concepts



9.6.4. Bicycle Lanes Adjacent to Parallel Parking and Loading

9.6.4.1 Minimum Width Bike Lane Considerations




Figure 9-10 Constrained Bike Lane Adjacent to Parking Example

Figure 9-11. Bike Lane with a Door Zone Buffer adjacent to Parking



9.12.3. Right Turn Lane Considerations




Figure 9-22: Example Right-Turn Only Lane with Shared Lane Markings

Figure 9-24: Example Bike Lanes on Streets +40 mph or Right-Turn Lanes +200 ft

Figure 9-26: Example Bike Lane Approach to a Through-Right and a Right-Turn Only Lane



Chapter 10 – Traffic Signals and Pedestrian Hybrid Beacons


- 10.1 Introduction
- 10.2 Design Guidance for Traffic Signal Control
- 10.3 Traffic Signal Phasing for Managing or Reducing Conflicts
- 10.4 Traffic Signal Timing for Bicyclists
- 10.5 Bicycle Signal Design Consideration
- 10.6 Detection for Bicycles
- 10.7 Design Guidance for Pedestrian Hybrid Beacons
- 10.8 Toucan Crossings with Traffic Signals

85

10.3.5. Signal Phasing Schemes for Reducing Conflicts

Table 10-1: Recommended Hourly Turning Traffic Thresholds for Time-Separated Bicycle Movements

	Left Turn Crossing One Vehicle Lanes	Left Turn Crossing Two Vehicle Lanes
One-Way Bike Lane	≥ 100 	≥ 50
Two-Way Bike Lane	≥ 50 	ANY



Legend
 bicyclist path of travel
 vehicle path of travel
 potential conflict

Figure 10-3: Left-Hook and Right-Hook Graphic

TOOLE
DESIGN

87

10.2.4. Traffic Signal Indication Options for Bicyclists

Bike signal head warrant:

- Leading or protected phasing
- Contra-flow movements
- Signal heads beyond cone of vision

Bike signal head application:

- Can only be used without conflicting vehicle turns




Figure 10-2: Examples of Signal Indication Options for Bicyclists

TOOLE
DESIGN

86

10.6. Detection for Bicycles 10.6.1.1 Pushbuttons for Bicyclists




Figure 10-12: Pushbutton Locations

DESIGN

88




Figure 10-13: Example of Curbside Bicycle Pushbutton

10.4.1. Green Time, Change Interval and Clearance Intervals for Bicyclists

Table 10-2: Bicycle Minimum Green Time Equation


Bicycle Minimum Green Time Equation	
$G_{min} = t + \frac{1.47V}{2a} + \frac{dL}{1.47V}$	
Where:	
G_{min}	= bicycle minimum green time (s)
V	= attained bicycle crossing speed (assumed 8 mph)
t	= perception reaction time (generally 1.5 s)
a	= bicycle acceleration (assumed 2.5 ft/s ²)
d	= distance from stop bar to middle of the intersection (ft)
L	= typical length of a bicycle (6 ft)

Vehicle Minimum Green - vs - Bicycle Minimum Green



11.3. Exit and Entrance Ramps

- On-road and off-road options
- Bike ramp to access to sidewalk
- Sidewalk becomes shared use path
- Perpendicular crossings



Chapter 11: Bicycle Facility Design at Interchanges, Alternative Intersections, and Roundabouts

- 11.1 Introduction
- 11.2 Basic Design Principles
- 11.3 Exit and Entrance Ramps
- 11.4 Multiple-Threat Conditions
- 11.5 Motorist Left Turns
- 11.6 Designs that Place Bicyclists in Constrained Areas
- 11.7 Conflicts between Bicyclists and Pedestrians in Shared Spaces
- 11.8 Channelized Right-Turn Lanes
- 11.9 Alternative Intersection Design Considerations
- 11.10 Roundabouts

11.3.3. Merging and Weaving Areas




Figure 11-9: Bike Lane Positioned in High-Exposure Weaving Area

11.7. Conflicts between Bicyclists and Pedestrians in Shared Space




Figure 11-11: Constrained Median Shared Use Path (10 ft wide) with Concrete Barrier Buffers

Figure 11-12: Side Path between Travel Lanes and Bridge Piers with Preferred Buffers



93

11.10. Roundabouts




Figure 11-16: Typical Layout of Bike Lane Transitions to Shared Use Path at Multilane Roundabout with Bike Ramps

Figure 11-17: Typical Layout of Separated Bike Lanes at Roundabout



95

11.8. Channelized Right-Turn Lanes




Figure 11-13: Channelized Right-Turn Lane Approach Angles

Figure 11-14: Channelized Right-Turn Refuge Island



94

Chapter 12 – Rural Area Bikeways and Roadways

- 12.1 Introduction
- 12.2 Safety Context of Rural Roads
- 12.3 Design User Profiles
- 12.4 Rural Bikeway Treatments
- 12.5 Pavement Surface Quality on Rural Roadways
- 12.6 Shared Use Paths and Sidepaths
- 12.7 Design Considerations for Bridges, Viaducts, and Tunnels in Rural Areas
- 12.8 Bicycle Travel Along Interstates, Freeways, and Limited-Access Highways
- 12.9 Roundabouts

96

12.4.3.2 Widths of Paved Shoulders

Table 12-1: Paved Shoulder Widths for Bicycling (see Chapter 12 References: FHWA, 2016b)

Design Year Average Daily Traffic (ADT) and Posted Speed (MPH) Thresholds	Practical Minimum ^a	Recommended Range		Practical Maximum
		Lower Limit ^b	Upper Limit	
< 2,000; all speeds	2 ft	3 ft	5 ft ^c	10 ft
2,000 - 6,000; all speeds	2 ft	4 ft	6 ft ^c	10 ft
6,000 - 10,000; all speeds	4 ft	6 ft	8 ft ^c	10 ft
> 10,000; ≤ 35 mph	5 ft	6 ft	8 ft ^c	12 ft ^d
> 10,000; > 40 mph ^e	5 ft	6 ft	10 ft ^d	12 ft ^d

Notes:
 See Section 12.5.1 for rumble strip design considerations.
^aWhere roadside barriers, walls, or other vertical elements are present, they should be offset a minimum of 2 ft from the outer edge of the rideable shoulder to provide minimum shy distance to bicyclists (see Section 2.5.3.2).
^bWhere > 10 percent of traffic consists of trucks.
^cShared use paths are preferred.



Figure 12-3: Shoulder Widening on Uphill Section of Roadway to Accommodate Bicycling

12.4.4. Advisory Shoulders (Experimental)

12.4.4. Advisory Shoulders (Experimental)

Similar to advisory bike lanes (see Section 9.8), advisory shoulders are an experimental design treatment for roads with lower traffic speeds and volumes where it is not feasible to provide standard bike lanes or shoulders for bicycle travel. When motor vehicles traveling in opposite directions meet, motorists may need to enter the advisory shoulder to create sufficient space to pass (see Figure 12-7). Experimental approval from FHWA is required to use this traffic control treatment. Where sidewalks are not present and it is desired for pedestrians to walk within the advisory shoulders, the advisory shoulder should be accessible to and usable by individuals with disabilities (see Section 1.6.3). See Section 1.6.1 for guidance on requests to experiment. See Section 9.8 and the FHWA Small Town and Rural Multimodal Networks Guide (see Chapter 12 Reference: FHWA, 2016a) for additional design guidance.



Figure 12-7: Example of Advisory Shoulders in Haveret, WI

Advisory shoulders may be considered in rural contexts on roads with the following characteristics:

Advisory shoulders may be considered in rural contexts on roads with the following characteristics:

- Low operating speeds
 - < 25 mph preferable
 - < 35 mph maximum
- Low to moderate motor vehicle volumes
 - < 3,000 vehicles/day preferable
 - < 6,000 vehicles/day maximum
- Infrequent heavy vehicles
- Adequate passing sight distance for motorists
- Regular bicycle traffic

If an advisory shoulder is being considered on a low-volume roadway with operating speeds above 25 mph, traffic calming treatments should be implemented to promote operating speeds at or below 25 mph.

Note: The use of this treatment requires a Request to Experiment from FHWA. See Section 1.6.1.

Section 12.3 - Design User Profiles

Design User:

Between Towns & Villages

- *Highly Confident*

In Towns & Villages

- *Interested but Concerned*



Figure 12-10: Subpath along a Rural Road





Figure 12-4: Bypass Lane with Paved Shoulder

12.5.1. Rumble Strip Placement and Design





Figure 12-8: Rumble Strip Placement Options



Definitions	
Length (A)	Dimension of rumble strip measured lateral to the travel lane
Width (B)	Dimension of rumble strip measured parallel to the travel lane
Depth (C)	Vertical distance measured from top of pavement surface to bottom of a rumble strip pattern
Spacing (D)	Dimension between rumble strip patterns
Clear Path (E)	Distance from outside (for example, right) edge of rumble strip to outside edge of paved shoulder
Gap (G)	Distance measured parallel to roadway, between groups of rumble strip patterns

^aNote: Figure not to scale.

Figure 12-9: Rumble Strip Minimum Gap Illustration

^bNote: Figure not to scale.

Figure 12-9: Rumble Strip Minimum Gap Illustration

^cNote: Figure not to scale.

Figure 12-9: Rumble Strip Minimum Gap Illustration

Chapter 13 – Structures

- 13.1 Introduction
- 13.2 General Design Principles for Structures
- 13.3 Design Details for Bridges
- 13.4 Design Details for Underpasses
- 13.5 Options for Retrofitting Existing Structures
- 13.6 Connections to Nearby Facilities

101

Chapter 14 – Wayfinding Systems for Bicyclists

- 14.1 Introduction
- 14.2 Core Wayfinding Approaches
- 14.3 When to Use Bicycle Wayfinding Signs
- 14.4 Design User Profile
- 14.5 Bicycle Wayfinding Approaches
- 14.6 Bicycle Wayfinding Sign Assemblies
- 14.7 Supplemental Information
- 14.8 Supplemental Wayfinding Elements
- 14.9 Wayfinding Sign Design: Style and Branding
- 14.10 Wayfinding Sign Placement and Installation
- 14.11 Wayfinding for Bicycle Detours and Work Zones

103

13.2. General Design Principles for Structures



Figure 13-1: Bikeway along the Interstate 90 Bridge over Lake Washington, WA




Figure 13-5: Horizontal Clearances for Shared Use Paths on Bridges Along Roads

TOOLE
DESIGN

102

14.6. Bicycle Wayfinding Sign Assemblies




Figure 14-4: Examples of Confirmation, Decision, and Turn Sign Assemblies

Table 14-1: Mileage Rounding Guidelines

Distance (mi)	Guideline
< 0.2	Do not include mileage; blocks are appropriate, if necessary
0.2 - 5.0	Round mileage to the nearest tenth of a mile
> 5.0	Round mileage to the nearest whole mile



Figure 14-7: Example of Community Wayfinding

TOOLE
DESIGN

104

Chapter 15 – Maintenance and Operations

- 15.1 Introduction
- 15.2 Maintenance Policy and Programs
- 15.3 Designing for Ease of Maintenance
- 15.4 Maintenance Activities
- 15.5 Temporary Traffic Control for Bicyclists (Maintenance of Traffic)

105

Chapter 16 – Bicycle Parking, Bike Share Siting, and End of Trip Facilities

- 16.1 Introduction
- 16.2 Planning for Bicycle Parking
- 16.3 Short-Term Parking
- 16.4 Long-Term Parking
- 16.5 Rack Design
- 16.6 Short-Term and Long-Term Bicycle Parking Site Design
- 16.7 Bike Parking at Special Events
- 16.8 Bike Share Parking
- 16.9 Locker Rooms, Showers, and Repair Stations (End-of-Trip Facilities)



107

15.2. Maintenance Policy and Programs




Table 15-1: Maintenance Equipment Types

Maintenance Equipment Types				
Type of Equipment	Corresponding Design Vehicle*	Width (ft) [†]	Height (ft)	Uses
3-Axle Single Unit Truck	SU-40	8	11-13	highway snow plowing, heavy construction, emergency vehicles
2-Axle Single Unit Truck	SU-30	8	11-13	ambulance, snow plowing, construction, routine maintenance
Pickup Truck	N/A	6-8	6-7	snow plowing, routine maintenance, law enforcement
Typical Skid-Steer Loader	N/A	5.5	6.5	snow plowing, routine maintenance, sweeping
Specialty Equipment	N/A	Varies by manufacturer		Varies

*For detailed information on vehicle geometry and turning radius, refer to Chapter 2 of AASHTO's A Policy on Geometric Design of Highways and Streets (See Chapter 15 References AASHTO, 2018).

[†]Width of attachments such as a sweeper blade or snow-plow blades may exceed the width of the vehicle.



106

16.3. Short-Term Parking

16.3.4. Example Designs with Unique Considerations





Table 16-1: Sample Short-Term Bicycle Parking Quantity Requirements

Types of Activity	Short-Term Parking Quantities	
	Most Contexts	Urbanized or High Bicycle Mode Share Areas ^a
Multi-unit residential dwellings	0.05 spaces per bedroom	0.10 spaces per bedroom
Libraries and government buildings	One space per 10,000 square ft of floor area	One space per 8,000 square ft of floor area
Church, theatres, stadiums, parks, beaches	Spaces for 2 percent of maximum expected attendance	Spaces for 5 percent of maximum expected attendance
Schools (K-12)	One space per 20 students	1.5 spaces per 20 students
Colleges and universities	One space per 10 students of planned capacity	One space per 10 students of planned capacity
Rail or bus terminals and airports	Spaces for 1.5 percent of a.m. peak passengers	Spaces for 2 percent of a.m. peak passengers
Retail- groceries	One space per 2,000 ft ² of floor area	One space per 2,000 ft ² of floor area
Retail- general	One space per 5,000 ft ² of floor area	One space per 5,000 ft ² of floor area
Office	One space per 20,000 ft ² of floor area	One space per 20,000 ft ² of floor area

^a A minimum of two bike parking spots is recommended in all cases.

Adapted from Anderson et al. (2010); see Chapter 16 References.



108

Thank you! Questions?

Jeremy Chrzan, PE, PTOE
Multimodal Design Practice Lead
jchrzan@tooledesign.com

